



INSTALLATION INSTRUCTIONS:

A- REMOVE BOTTOM ACCESS PANEL (1) FROM -SK5 HOUSING.

B- USING -SK5 SKIRT AS A TEMPLATE, ALIGN TOP MOUNTING POINTS WITH FIXTURE OPENING AND MARK AND LOCATE VERTICAL MOUNTING HOLES (2) ON FOUNTAIN BOTTOM SKIRT (3).

C- REMOVE FIXTURE BOTTOM SKIRT (3) AND DRILL PILOT HOLES INDICATED ABOVE USING 1/8" DRILL BIT FOR #8 SHEET METAL SCREWS (4) PROVIDED.

D- RE-INSTALL BOTTOM SKIRT (3) TO FIXTURE.

E- INSTALL -SK5 TO FIXTURE AS REQUIRED USING SHEET METAL SCREWS (4) PROVIDED.

murdock[®]

P.O. Box 3527 Industry, CA 91744
15125 Proctor Ave., City of Industry, CA 91746
(800) 453-7465 (626) 333-2543 www.murdockmfg.com

TITLE **-SK5 ACORN ACCESS BI-LEVEL SKIRT ASSEMBLY**

MANUFACTURE DATE
JANUARY 2012
TO PRESENT

DATE ISSUED
01/16/12
DATE REVISED
07/25/17 A

DRAWING NUMBER
9938-391-001