


B-0111, B-0111-B, B-0112



See page 11 for part explosion

Pre-Rinse Assembly

1	Asm, 'L' Tube, 12" (B-0111 & B-0111-	002882-40	18	Index, Button, Blue/Cold	001660-45
2	L' Tube 12"	000384-40		Index, Button, Red/Hot	001661-45
3	Nut, Pre-Rinse	000735-40	19	Handle, Lever	001638-45
4	Stem, Pre-Rinse	000839-25	20	Asm, Spindle Eterna - Cold	002711-40
5	O-Ring, Pre-Rinse	001074-45		Asm, Spindle Eterna - Hot	002712-40
6	Body, Pre Rinse	000591-25	21	Washer	002290-45
7	Asm, 'L' Tube, 18" (B-0112)	002883-40	22	Locknut	000965-45
8	L' Tube 18"	000358-40	23	Nut, Spreader	000736-20
9	Nut, Pre-Rinse	000735-40	24	Gasket	001041-45
10	Stem, Pre-Rinse	000839-25	25	Asm, Spreader Unit	002898-40
11	O-Ring, Pre-Rinse	001074-45	26	Asm, Hose and Handle, Stainless Steel	B-0020-H
12	Body, Pre Rinse	000591-25	27	Asm, Wall Bracket	B-0109-01
13	Screw, Finger Hook	000916-45	28	Set Screw	001584-45
14	Finger Hook	000021-40	29	Nipple, 6"	000346-40
15	Nipple, 3/8" x 32"	000376-40	30	Screw, Wall Mount	000915-45
16	Asm, Base Faucet	002824-40	31	Tailpiece	001592-20
17	Screw, Handle	000922-45	32	Nut	000958-20

