


B-2992, B-2992-P



Faucet Assembly

1	Screw, Handle	000925-45	9	Nut, Coupling	000958-20
2	Index, Snap-In, Blue/Cold	001686-45	10	Nipple	000342-20
	Index, Snap-In, Red/Hot	001194-45	11	Locknut	002954-45
3	Handle, Lever	001638-45	12	O-Ring, Knuckle Joint	001060-45
4	Escutcheon	001257-40	13	Locknut, Yoke	000956-45
5	Asm, Spindle, Eterna - RH/Cold	006478-40	14	Washer, Swivel Yoke, Top	000994-45
	Asm, Spindle, Eterna - LH/Hot	006477-40	15	O-Ring, Swivel Yoke, Center	001068-45
6	Locknut, Body Top	000959-20	16	Washer, Swivel Yoke, Bottom	000993-45
7	Locknut, Body Bottom	000960-20	17	Washer, Yoke Star	000982-45
8	Washer	000981-45	18	Aerator	B-0199-03

