


BATTERY FOUNTAINS

Model 10490

(Obsolete)



FOUNTAIN 10490 PARTS LIST

| REF NO | PART NUMBER | DESCRIPTION |
|--------|---------------------|--------------------------------|
| 1 | 16-03165-08-640 | Projector (3 each) |
| 2 | 10-03227-40-560 | Gasket (6 each) |
| 3 | 16-06092-08-550 | Projector Nipple (3 each) |
| 4 | 10-10474-42-550 | Stream Breaker (3 each) |
| 5 | 16-16373-08-640 | Drain Plug (3 each) |
| 6 | 16-02705-08-640 | Strainer Plate (3 each) |
| 7 | 10-01471-40-560 | Gasket (3 each) |
| 8 | 60-08240-51-640 | Push Button Assembly (3 each)* |
| 9 | No Longer Available | Regulator |
| 10 | No Longer Available | Waste Line Assembly |
| 11 | No Longer Available | Supply Line Assembly |
| 12 | No Longer Available | Trap |
| 13 | No Longer Available | Receptor |
| 14 | No Longer Available | Hanger Bracket |

* Look for detailed schematic of this part in Detailed Parts Section

To order parts, contact your nearest Halsey Taylor wholesaler or representative.

Continued product improvement makes specifications subject to change without notice.

Halsey Taylor.

P.O. BOX 9001
OAKBROOK, ILLINOIS 60521