

MODEL WC 7A-1

WC 7A-1 PART LIST

REF NO.	PART NUMBER	DESCRIPTION
1	16-03165-08-640	Projector
2	10-03227-40-560	Projector Gasket (2 each)
3	16-06092-08-550	Projector Nipple
4	10-10474-42-550	Stream Breaker
5	60-14837-51-550	Regulator Assembly*
5a	60-08050-51-550	Diaphragm Repair Kit (for item 5)*
5b	60-14829-51-550	Stem Assembly*
6	16-16373-08-640	Drain Plug
7	16-02705-08-640	Strainer Plate
8	10-01471-40-560	Waste Gasket
9	16-03560-08-550	Tailpiece
10	16-03463-08-640	Slipnut
11	16-03462-20-550	Locknut
12	10-03529-40-560	Slipnut Gasket
13	16-10712-08-640	Handle (2 each)
14	11-10718-42-550	Set Screw for Handle (2 each)
15	41-10706-08-640	Rod Bushing (2 each)
16	11-10719-43-010	Locknut (2 each)
17	10-10711-43-550	Activating Rod
18	60-10710-51-550	Valve Plate
19	40-10705-42-010	Receptor
20	11-07119-42-550	Receptor Screws (4 each)
21	11-07447-43-550	Speed Nut (4 each)
22	40-06609-43-730	Receptor Hanger (not shown)
23	16-00234-08-550	Trap
24	60-10330-51-550	Lowside Assembly
25	19-42339-51-550	Primary Temperature Control
26	19-15342-51-550	Secondary Temperature Control
27	60-08394-51-550	Compressor Assembly
27a	19-07765-51-550	Relay (included in item 27)
27b	19-07724-51-550	Overload (included in item 27)
27c	19-10858-82-550	Capacitor (included in item 27)
28	19-10301-51-550	Condenser
29	60-10333-51-550	Fan and Motor Assembly
29a	19-06487-04-550	Fan Blade (included in item 29)

XXX Please specify color when ordering. See Color Chart on page I-A for colors available.

*See Detailed Parts Section for further breakdown.

