

#### INSTALLATION, OPERATION & MAINTENANCE INSTRUCTIONS

1455 Kleppe Lane •Sparks, NV 89431-6467 •(775) 359-4712 •Fax (775) 359-7424 HAWS AG •Bachweg 3 •CH-3401 Burgdorf • Switzerland Haws Mfg. Pte Lt. •2A Sungei Kadet Drive •Singapore 729554 Avlis-Avenido Senador, Testonio Vilela •505 Jardim Aeroporto • Itu, S.P. 13304-550 •Brasil E-mail: haws@hawsco.com • website: www.hawsco.com

No. 2080086(11)

## Model 7752WC Eye/Face Wash

NOTE TO INSTALLER: Please leave this information with the Maintenance Department.

#### LIMITED WARRANTY

HAWS<sup>®</sup> warrants that all of its products are guaranteed against defective material or poor workmanship for a period of **one year from date of shipment.** HAWS liability under this warranty shall be discharged by furnishing without charge F.O.B. HAWS Factory any goods, or part thereof, which shall appear to the Company upon inspection to be of defective material or not of first class workmanship, provided that claim is made in writing to company within a reasonable period after receipt of the product. Where claims for defects are made, the defective part or parts shall be delivered to the Company, prepaid, for inspection. HAWS will not be liable for the cost of repairs, alterations or replacements, or for any expense connected therewith made by the owner or his agents, except upon written authority from HAWS, Sparks, Nevada. HAWS will not be liable for any damages caused by defective materials or poor workmanship, except for replacements, as provided above. Buyer agrees that Haws has made no other warranties either expressed or implied in addition to those above stated, except that of title with respect to any of the products or equipment sold hereunder and that HAWS shall not be liable for general, special, or consequential damages claimed to arise under the contract of sale.

The emergency equipment manufactured by HAWS is warranted to function if installation and maintenance instructions provided are adhered to. The units also must be used for the purpose, which they were intended. This product is intended to supplement first-aid treatment. Due to widely varying conditions HAWS cannot guarantee that the use of this emergency equipment will prevent serious injury or the aggravation of existing or prior injuries.

NO OTHER WARRANTIES EXPRESSED OR IMPLIED ARE AUTHORIZED, PROVIDED OR GIVEN BY HAWS.

SHOULD YOU EXPERIENCE DIFFICULTY WITH THE INSTALLATION OF THIS MODEL, PLEASE CALL:

### 1-800-766-5612

FOR PARTS CALL:

# 1-800-758-9378


(U.S.A. AND CANADA ONLY) MONDAY-THURSDAY: 6:00 A.M. – 4:00 P.M. PST FRIDAY: 6:00 A.M – 1:00 P.M. PST **LOCATION OF UNIT:** The Model 7752WC Emergency Eye/Face Wash should be installed in close proximity to potential accident areas. It should be clearly identified, free from obstructions and easy to access.


**SUPPLY LINE:** The minimum recommended line size is 1/2" IPS with 30-90 psi (2-6 ATM) pressure. Where sediment or mineral content is a problem, an inlet filter is recommended.

TROUBLESHOOTING PROBLEM **REPAIR CHECKLIST** No flow. 1. Check the main shut-off valve. 1. 2. 2. a. Verify minimum 30 psi (2 ATM) Insufficient water flow. flowing supply line pressure. b. Probable clogging of flow control due to inadequate line flushing. Unscrew eye/face wash head and remove the four screws to disassemble the head. Clean flow control and reassemble head. See SP65 Installation drawing for details. 3. a. Possible blocked flow control, see 3. Eyewash stream does not meet desired eye level. above solution. b. Possible non-leveled eyewash assembly. Water does not drain properly. 4. Check the main waste line of your 4. building to see if it does handle the capacity required for the entire drainage system.

PLUMBING CONNECTIONS: Inlet supply is 1/2" IPS. Waste outlet is 1 1/4" IPS.

© 2006 Haws<sup>®</sup> Corporation – All Rights Reserved HAWS<sup>®</sup> and other trademarks used in these materials are the exclusive property of Haws Corporation.





Page 4 of 4

00400860.0M 1